



Aquaflash 500 Installation Instruction

1. Aquaflash 500 should be cut into manageable lengths of approximately 8 to 10 feet.
2. Remove the release liner.
3. Apply Aquaflash 500 membrane starting from the lowest point and work upwards.
4. Once the membrane is in place, use a steel hand roller to secure the flashing firmly in place.
5. All side laps should be a minimum of 2 1/2". Either trim edges or lay the membrane 1/2" back from face of masonry.
6. Inside and outside corners must be covered with two layers of membrane and sealed with mastic.

Once installed, no maintenance is required.

Note: Not to be used for exposed flashing.

Not to be applied below 25°F Not to be applied below 40°F without a primer

Not to be used with oil based, wax based or polysulfide sealants or creosote.

Rubberized asphalt flashings not to be exposed for more than 3-4 weeks.

Storage:

Temperature not to exceed 120° Fahrenheit or go below 25° Fahrenheit.

Protect products from inclement weather or excessive heat.

Sizes: Standard Widths: 12", 16", 18" 24",36" Standard Length: 50 lineal feet.

Corporate Office: 400 Roundtree Rd Charlotte, NC 28217
TEL: (800) 849-6722 FAX: (704) 525-3761

Mailing Address: P.O. Box 240988 Charlotte, NC 28224



Memphis Plant: 2365 Harbor Ave. Memphis, TN 38113
TEL: (800) 441-8359 FAX: (901) 775-9449

Mailing Address: P.O. Box 13124 Memphis, TN 38113